

FRAME PREP FOR STRIKE

1. PREPARE JAMB AS SHOWN IN FIG. #1.
2. INSTALL STRIKE USING SCREWS SHOWN.
3. CLOSE DOOR AND ADJUST STRIKE TO HOLD DOOR TIGHT AGAINST WEATHERING.



